

# Monitor Upgrade Solution v2.1

## Linux User's Guide

This edition applies to Monitor Upgrade Solutions 2.1 for Linux and to all subsequent releases and modifications until otherwise indicated in new editions.

Address your comments to:

**Toshiba Global Commerce Solutions**

3901 S. Miami Blvd  
Durham  
North Carolina 27703  
United States

When you send information to TOSHIBA, you grant TOSHIBA a nonexclusive right to use or distribute whatever information you supply in any way it believes appropriate without incurring any obligation to you.

**2016 © Copyright Toshiba Global Commerce Solutions**

**January 2016 (Version 1.05)**

## Table of Contents

<b>1 Introduction to MUS</b>	3
1.1 What is Monitor Upgrade Solution	3
<b>2 MUS Contents</b>	3
2.1 Operational Package (OP)	3
2.1.1 File format	3
2.1.2 Components of OP	3
2.2 Upgrade Packages (UP)	3
2.2.1 File format	3
2.2.2 RPM Dependency	4
<b>3 Pre Requisites</b>	4
3.1 Supported Linux OS	4
3.1.1 Required Minimum Kernel Levels	4
3.2 Supported Displays	4
3.3 Python 2.6 Environment	4
3.3 Zypper command line tool	4
<b>4 MUS 2.1 Installation</b>	4
4.1 Cleaning the system for a previous version of MUS Installed	5
4.1.1 Cleaning previous version of MUS 1.0 from the system	5
4.1.2 Cleaning previous version of MUS 1.1/2.0 from the system	5
4.2 MUS 2.1 OP Installation	5
4.3 MUS 2.1 UP Installations	5
4.3.1 Manual Install	6
4.3.2 Install at boot time (via RpmUpdates directory)	6
<b>5 MUS 2.1 Uninstallation</b>	6
5.1 MUS 2.1 UP Un-installation	6
5.2 MUS 2.1 OP Un-installation	7
<b>6 How MUS Works</b>	7
6.1 Normal Update Cycle	8
6.2 Recovery Update Cycle	8
<b>7 Updating Touch Configurations</b>	8
7.1 4820-21X/51X and 4820-2LX/5LX Touch Configuration Update	8
7.2 6149-5XX Touch Configuration Update	9
<b>8 Updating Touch Firmware</b>	9
<b>9 Updating Video Firmware</b>	9
<b>10 MUS Directory Structure</b>	9
10.1 MUS base directory	9
10.2 Logs Directory	10
<b>11 Known Limitations</b>	12

# 1 Introduction to MUS

## 1.1 What is Monitor Upgrade Solution

The Monitor Upgrade Solution (MUS) is a solution by Toshiba Global Commerce Solutions, Inc. to perform silent and remote updating of the Touch and Video Firmware of Toshiba Monitor types 4820 21X/51X, 4820 2LX/5LX and 6149-5XX. Monitor Upgrade Solution is composed of two parts.

- First is the Operational Package (OP), this is needed to be pre-installed to the system for the MUS solution to operate. This is the base mechanism for upgrading. It contains the monitor upgrade service and other support executables.
- Secondly, there will be an upgrade-specific upgrade package (UP) for the actual upgrade to be done. And this package is made when a critical firmware change is released by a vendor. So for example there may be a release of new firmware for 4820 21X/51X Video micro-controller - in this case a 4820 21X/51X Video firmware UP will be created by TGCS and tested. This will then be released to customers. Similarly another critical touch firmware change may be released by the touch vendor for 4820 2LX/5LX. Another UP will be created by TGCS, tested and released. Each upgrade is domain specific.

# 2 MUS Contents

## 2.1 Operational Package (OP)

This is the basic mechanism needed to perform firmware and other upgrades on a POS System with newer 4820 XLX and X1X models. It consists of Monitor Upgrade Service scripts which run at boot time in order to perform monitor upgrade tasks.

### 2.1.1 File format

The OP will be in an RPM in this format `<name>-<version>-<release>.<arch>.rpm`

Example: `toshiba-mus_op-suse-2.1-1.noarch.rpm`

### 2.1.2 Components of OP

The components included in the Operational Package are:

- ❖ Monitor Upgrade Service support scripts
- ❖ 4820 Monitor Video firmware update utility - **4820MonUtil**
- ❖ Touch firmware update utilities - **elo\_config** and **elo\_download**
- ❖ 6149 Monitor Video firmware update utility - **aipfwupdate**
- ❖ Ocular/Atmel Touch firmware update utilities - **mxt-app**

## 2.2 Upgrade Packages (UP)

The Upgrade Packages contain the actual Upgrade Tasks to be performed by the Monitor Upgrade Service.

Typically they provide the updated touch or video firmware files along with a manifest and any support files required. Each represents a compact atomic upgrade task.

UP Tasks are run by the Monitor Upgrade Service at system boot time.

### 2.2.1 File format

The UPs are also RPMs with format `name-version-release.arch.rpm`

### 2.2.2 RPM Dependency

Requires: toshiba-mus\_op-suse >= 2.1

Example: toshiba-mus2.1\_up\_4820-21X51X\_touch-fw\_010d-1.0-1.noarch.rpm

## 3 Pre Requisites

### 3.1 Supported Linux OS

- ❖ SLES 11 SP3 32-Bit
- ❖ SLED 11 SP3 32-Bit
- ❖ SLEPOS 11 SP3 32-Bit

#### 3.1.1 Required Minimum Kernel Levels

1. For "default" kernel setup  
kernel-default-3.0.101-0.5.1.i586.rpm  
kernel-default-base-3.0.101-0.5.1.i586.rpm
2. For "pae" kernel setup  
kernel-pae-3.0.101-0.5.1.i586.rpm  
kernel-pae-base-3.0.101-0.5.1.i586.rpm

### 3.2 Supported Displays

- ❖ Toshiba SurePoint Display 4820 (Model 21x, 51x, 2Lx, 5Lx)
- ❖ Toshiba TCx Display 6149 (Model 5Cx, 5Nx, 5Sx)

### 3.3 Python 2.6 Environment

Python 2.6 is a default package included with SLES 11 and SLED 11, however SLEPOS sometimes may not have included Python 2.6. So a user needs to check if the SLEPOS environment has it.

Download the latest version of Python 2.6 in the link below if needed.

<http://www.python.org/download/releases/2.6.8/>

### 3.3 Zypper command line tool

Zypper is a default package included with SLES, SLED. If this package is not installed then the user needs to install this package.

**For SLEPOS Users:**

This is not a default package. Therefore, the user needs to include the Zypper package when they create their SLEPOS image.

## 4 MUS 2.1 Installation

MUS 2.1 and lower versions (< 2.1) are incompatible and cannot co-exist on the same system. If lower version of MUS OP is installed in the system, the user **MUST** uninstall this first before installing the new MUS 2.1 OP rpm file. This will ensure that there will be no file or driver conflicts between the two OPs.

## 4.1 Cleaning the system for a previous version of MUS Installed

### 4.1.1 Cleaning previous version of MUS 1.0 from the system

Remove MUS 1.0 install file tree and binaries by using the uninstall script provided.

```
# /opt/toshiba/UNINSTALL/MUS_Uninstall
```

#### **IMPORTANT:**

Also remove the independent elofousb-kmp kernel driver package using rpm uninstall

```
# rpm -ev elofousb-kmp-pae-1.0_3.0.13_0.27-4
```

```
# rpm -ev elofousb-kmp-default-1.0_3.0.13_0.27-4
```

### 4.1.2 Cleaning previous version of MUS 1.1/2.0 from the system

Remove MUS 1.0 install file tree and binaries by using the uninstall script provided.

```
# /opt/toshiba/mus/mus_op_uninstall
```

## 4.2 MUS 2.1 OP Installation

Execute the following command:

```
# rpm -ivh toshiba-mus_op-suse-2.1-1.noarch.rpm
```

#### **NOTE:**

MUS currently will not support “rpm upgrade options” meaning, user cannot install a new MUS OP with the command “rpm -Uvh toshiba-mus\_op-suse-2.1-1.noarch.rpm”

This installs just the basic upgrade mechanisms. No Upgrade Tasks are installed yet.

## 4.3 MUS 2.1 UP Installations

Each Upgrade Task is contained in its own RPM package.

These RPMs will install UP task files under a folder called */opt/toshiba/mus/UpdateTasks/*. Each task (video, touch, touch configuration) will be installed into its appropriate part of the sub-tree.

A user may install the UP RPM manually or let the MUS install the UP RPM by “dropping” it into a UP stage folder called */opt/toshiba/mus/RpmUpdates*. The MUS will install any UP rpm(s) found in the stage folder.

#### 4.3.1 Manual Install

```
#rpm -ivh toshiba-mus2.1_up_4820-21X51X_touch-fw_010d-1.0-1.noarch.rpm
```

#### 4.3.2 Install at boot time (via RpmUpdates directory).

The */opt/toshiba/mus/RpmUpdates* is the directory where the UP RPMs must be placed when there are new UP available. These RPMS will get installed by the Monitor Upgrade Service on the next system reboot. After uninstallation, the RPM package will be removed from this directory.

### Currently known MUS 2.1 UP Tasks:

- **Elo Touch Configuration Update**  
File Name: toshiba-mus2.1\_up\_2xx5xx\_touch-config\_elo-1.0-**n**.noarch.rpm
- **4820-2LX/5LX USB touch monitor Touch Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_4820-2LX5LX\_touch-fw\_XXXX-1.0-**n**.noarch.rpm
- **4820-2LX/5LX USB touch monitor Video Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_4820-2LX5LX\_video-fw\_XXXX-1.0-**n**.noarch.rpm
- **4820-21X/51X USB touch monitor Touch Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_4820-21X51X\_touch-fw\_XXXX-1.0-**n**.noarch.rpm
- **4820-21X/51X USB touch monitor Video Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_4820-21X51X\_video-fw\_XXXX-1.0-**n**.noarch.rpm
- **6149-5XX USB touch monitor Touch Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_6149\_touch-**GUID**-1.0-**n**.noarch.rpm
- **6149-5CX USB touch monitor Video Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_6149-5CX\_video-XXXX\_XXXX-1.0-**n**.noarch.rpm
- **6149-5NX/5SX USB monitor Video Firmware Upgrade**  
File Name: toshiba-mus2.1\_up\_6149-5NXSX\_video-XXXX\_XXXX-1.0-**n**.noarch.rpm

### NOTE:

1. **XXXX** is the version of the firmware.
2. **n** is the incremental version of the UP which normally contains bug fixes and always start from 1.
3. **GUID** is the Globally Unique Identifier with 22 characters to identify the content of the UP. Since MUS 2.1, the firmware version of the UP will no longer be included in the UP name as it may contain multiple firmware versions in a UP. User has to check on the release note for the firmware versions it contains.

## 5 MUS 2.1 Uninstallation

### 5.1 MUS 2.1 UP Un-installation

Tasks may be uninstalled by a user via RPM at any time. This is not done by the Monitor Upgrade Service.

(i.e. # rpm -ev toshiba-mus2.1\_up\_4820-21X51X\_touch-fw\_010d-1.0-1.noarch.rpm )

## 5.2 MUS 2.1 OP Un-installation

Run the script “*mus\_op\_uninstall*” found at the directory */opt/toshiba/mus*. This script takes care of dependencies created by the UP installations.

**Note:** Running an rpm command to uninstall the OP rpm will fail when one or more UP(s) are installed.

(i.e. # rpm -ev toshiba-mus\_op-suse-2.1-1.noarch.rpm )

## 6 How MUS Works

The Monitor Upgrade Service is installed as a Linux Service. It will run at boot time. In the Normal case the Monitor Upgrade Service will run a Normal Update Cycle.

If there are recoverable failure scenarios encountered during the Normal Update Cycle the Monitor Upgrade Service will stop processing upgrades and reboot again in order to run a Recovery Cycle.

A recoverable failure is one where the manufacturer has provided failure recovery as part of their supplied utility. An example of a recoverable failure scenario is when power is removed from the Monitor during the actual byte transfer update part of a video firmware update task for 4820.

### Recoverable Scenarios:

#### 1. Interruption when touch firmware flashing

##### Supported Interruption:

- Power Loss/ Unplug Power cable
- Unplugging of Power USB cable

##### Supported Displays:

- 4820-2LX/5LX
- 6149-5XX

#### 2. Interruption when video firmware flashing

##### Supported Interruption:

- Power Loss/ Unplug Power cable
- Unplugging of Power USB cable

##### Supported Displays:

- 4820-2LX/5LX
- 4820-21X/51X
- 6149-5XX

**Note:** Please refer to the **Section 11. Known Limitations** for what is not currently supported type of firmware flash interruption. Configuration updates do not have any built-in recovery mechanism.

## 6.1 Normal Update Cycle

1. MUS will install any UP Task RPM packages it finds in RpmUpdates - if it is not already installed – and will then move the RPM files for successfully installed packages to: `/opt/toshiba/mus/ProcessedRpms`

**NOTE:** *MUS 2.1 OP will not support UP task RPM other than those mention in the available UP Tasks in Section 4.3*

2. After installing the UP Task RPM a new sub-tree folder corresponding to that update level is created.

Example: `/opt/toshiba/mus/UpdateTasks/Touch/toshiba-mus2.1_up_4820-21X51X_touch-fw_010d/`

3. MUS will then check if there are any appropriate installed update tasks to be executed for any of the currently connected monitors.

This is done by comparing the current update level (both touch and video) of all attached monitors to the current greatest update level in all UP Task manifests.

4. MUS will then execute all the necessary update tasks in sequence (one or many).
5. Configuration Tasks will always be applied. This is much faster than querying USB controller devices and then deciding whether update is needed.
6. All tasks will be attempted and will only abort the processing if there is a task failure. If a task failed, then MUS will abort. If the task is recoverable, MUS will then reboot and perform a recovery cycle – see Section 6.2.
7. If there is no error then after any and all tasks are completed MUS will exit. There will be no reboot required.

## 6.2 Recovery Update Cycle

1. The recoverable task will be re-attempted using the specific recovery processing by the vendor support utility.
2. If recovery routine is successful, MUS will reboot the system one more time to put it back to working state.
3. If the recovery fails MUS will try to attempt recovery one more time.
4. If (all) recovery attempts have failed MUS will exit the Recovery cycle and then reboot the system to Normal update cycle. RECOMMENDED PROCEDURE at this point is to unplug and remove the affected monitor. Field Support may be required.
5. If the recovery succeeds, MUS will exit and reboot the system to bring it to a consistent state and boot into Normal update cycle.

**NOTE:** The duration of a single recovery, 1 firmware update, is approximately 10 minutes. The time may vary from system to system depending on its speed. The approximated time is from attempting to reboot the system, do the recovery routine, reboot the system again and boot to normal user session.

# 7 Updating Touch Configurations

## 7.1 4820-21X/51X and 4820-2LX/5LX Touch Configuration Update

1. Install UP rpm for Touch Configuration

**NOTE:** *MUS 2.1 OP will not support UP task RPM other than those mention in the available UP Tasks in Section 4.3*

2. Modify the configuration file “`/opt/toshiba/mus/UpdateTasks/TouchConfig/EloTouch/eloConfigOpt.ini`” for desired settings.
3. Reboot the system.



4. All attached 4820 monitors now should show the Touch configurations specify in the configuration file.

## 7.2 6149-5XX Touch Configuration Update

For 6149-5XX monitors, Touch Configurations are bundled together with the Firmware Update packages. This configuration is not intended to be modified by the user. If there are any touch configuration updates available, a new UP will be release and this will be the only way to update the existing configurations.

**NOTE:** This touch configuration will be loaded to all attached 6149-5XX Monitors every time the system reboots .This is to ensure that the monitors will always have the same configurations.

## 8 Updating Touch Firmware

1. Install UP rpm for new Touch Firmware or place this UP rpm at */opt/toshiba/mus/RpmUpdates* folder for auto install on boot-time.

**NOTE:** *MUS 2.1 OP will not support UP task RPM other than those mention in the available UP Tasks in Section 4.3*

2. Reboot the system
3. All attached designated monitors will now have the new Touch Firmware level.

## 9 Updating Video Firmware

1. Install UP rpm for new Video Firmware or place this UP rpm at */opt/toshiba/mus/RpmUpdates* folder for auto install on boot-time.

**NOTE:** *MUS 2.1 OP will not support UP task RPM other than those mention in the available UP Tasks in Section 4.3*

2. Reboot the system
3. All attached designated monitors will now have the new Video Firmware level.

## 10 MUS Directory Structure

Describe below are the well - known directories that the user can refer to about MUS.

### 10.1 MUS base directory

This will be the root directory for all of the upgrade solution functionality containing:

- ❖ OP support scripts (ex. ELO,SAMPO)
- ❖ UP RPM Directories
- ❖ Update Tasks Folder

#### MUS ROOT DIRECTORY

*# /opt/toshiba/mus/*

## 10.2 Logs Directory

This directory contains the log for all MUS operations including OP Installation, log history and the latest MUS log.

### **OP\_INSTALLATION:**


*# /var/log/toshiba/mus/op\_installation/*

### **LOG HISTORY:**

*# /var/log/toshiba/mus/history/*

### **LATEST LOG:**

*# /var/log/toshiba/mus/latest/*



## 11 Known Limitations

1. MUS 2.1 Linux does not support power loss/ unplug power cable and unplugging of power USB cable from the attached **4820-21X/51X** monitor while a **touch** firmware update is ongoing. Doing so will cause undesirable damage to the firmware and perhaps to the monitor itself.
2. A possible segmentation fault occurs when a configuration of both **6149 (Model 5Cx, 5Nx, 5Sx)** and **4820 (Model 21x, 51x, 2Lx, 5Lx)** Monitor types are attached in a POS system while performing a video firmware update for the **6149 (Model 5Cx, 5Nx, 5Sx)** Monitors. This is a known issue being thrown by the library libusb-1.0 version 1.0.8 when doing asynchronous bulk transfer. This library is being use by the video firmware update utility. To recover firmware update, the customer **MUST remove** the **4820 (Model 21x, 51x, 2Lx, 5Lx)** Monitors first before rebooting the system to trigger firmware update.